

Eaton DX RT Online UPS

6000/10000VA(XL) IN USER MANUAL



Powering Business Worldwide

Service and support

Call your local service representative

Safety Instructions

SAVE THESE INSTRUCTIONS. This manual contains important instructions that should be followed during installation and maintenance of the UPS and batteries.

The UPS models that are covered in this manual are intended for installation in an environment within 0 to 50°C, free of conductive contaminant.

Certification standards

- Safety: EN 62040-1
- EMC: IEC/EN 62040-2
- IEC 61000-4-2 (ESD): level 3.
- IEC 61000-4-3 (Radiated field): level 3.
- IEC 61000-4-4 (EFT): level 4.
- IEC 61000-4-5 (Fast transients): level 4.
- IEC 61000-4-6 (Electromagnetic field): level 3.
- IEC 61000-4-8 (Conducted magnetic field): level 4.
- Performance: IEC/EN 62040-3

Special symbols

The following are examples of symbols used on the UPS or accessories to alert you to important information:



RISK OF ELECTRIC SHOCK - Observe the warning associated with the risk of electric shock symbol.



Important instructions that must always be followed.



Do not discard the UPS or the UPS batteries in the trash.

This product contains sealed lead acid batteries and must be disposed as it's explain in this manual. For more information, contact your local recycling/reuse or hazardous waste center.



This symbol indicates that you should not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.



Information, advice, help.



Refer to the user manual.

Safety of persons

- RISK OF VOLTAGE BACKFEED. The system has its own power source (the battery). Isolate the UPS and check for hazardous voltage upstream and downstream during lockout-tagout operation. Terminal blocks may be energized even if the system is disconnected from the AC power source.
- Dangerous voltage levels are present within the system. It should be opened exclusively by qualified service personnel.
- The system must be properly grounded.
- The battery supplied with the system contains small amounts of toxic materials. To avoid accidents, the directives listed below must be observed:
 - Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.
 - When replacing batteries, replace with the same type and number of batteries or battery packs.
 - Do not dispose of batteries in a fire. The batteries may explode.
 - Batteries constitute a danger (electrical shock, burns). The short-circuit current may be very high.
- Precautions must be taken for all handling:
 - Wear rubber gloves and boots.
 - Do not lay tools or metal parts on top of batteries.
 - Disconnect charging source prior to connecting or disconnecting battery terminals.
 - Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).

Product safety

- The UPS connection instructions and operation described in the manual must be followed in the indicated order.
- CAUTION - To reduce the risk of fire, the unit connects only to a circuit provided with branch circuit overcurrent protection for :
63A rating, for 6kVA models,
100A rating, for 10kVA models
- The upstream circuit breaker for Normal AC/Bypass AC must be easily accessible. The unit can be disconnected from AC power source by opening this circuit breaker.
- An additional AC contactor is used for backfeed protection and must comply with IEC/EN 62040-1 (the creep age and clearance distances shall meet the basic insulation requirements for pollution degree 2).

- Disconnection and overcurrent protection devices shall be provided by others for permanently connected AC input (Normal AC/Bypass AC) and AC output circuits.
- Check that the indications on the rating plate correspond to your AC powered system and to the actual electrical consumption of all the equipment to be connected to the system.
- For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible
- Never install the system near liquids or in an excessively damp environment.
- Never let a foreign body penetrate inside the system.
- Never block the ventilation grates of the system.
- Never expose the system to direct sunlight or source of heat.
- If the system must be stored prior to installation, storage must be in a dry place.
- The admissible storage temperature range is -25°C to +60°C with battery(-15°C to +40°C without battery).

Special precautions

- The unit is heavy: wear safety shoes and use vacuum lifter preferentially for handling operations.
- All handling operations will require at least two people (unpacking, lifting, installation in rack system).
- Straps are provided only for unpacking manually the unit from the carton; don't use the straps to carry the unit around. The unit can slip from the straps during handling (risk of injury and product damage):
 - keep 12in / 30cm minimum distance between the straps
 - lift the unit carefully and keep it at low height
 - keep the unit horizontal during unpacking.
- Before and after the installation, if the UPS remains de-energized for a long period, the UPS must be energized for a period of 24 hours, at least once every 6 months (for a normal storage temperature less than 25°C). This charges the battery, thus avoiding possible irreversible damage.
- During the replacement of the Battery Module, it is imperative to use the same type and number of element as the original Battery Module provided with the UPS to maintain an identical level of performance and safety.

Contents

1. Introduction	1
1.1 Environmental protection.....	1
1.2 Electronic equipment protection	2
2. Presentation.....	3
2.1 RT Front panel.....	3
2.2 RT Rear panels.....	3
2.3 EBM Front panel:	4
2.4 EBM rear panel:.....	4
2.3 Circuit diagram.....	4
3. Installation	5
3.1 Inspecting the equipment	5
3.2 Unpacking the Unit.....	5
3.3 Checking the accessory kit	6
3.4 Install the unit.....	7
4. Power cables connection.....	10
4.1 Access to terminal blocks (AC source to UPS)	11
4.2 Access to terminal blocks (PDU source to R/T UPS)(Optional).....	12
4.3 Parallel Installation and Operation (Optional).....	12
5. Operation.....	17
5.1 Control panel.....	17
5.2 LCD description	19
5.3 Display functions	21
5.4 User settings	22
5.5 UPS startup and shutdown	23
5.6 LCD operation.....	25
6. Communication	33
6.1 Communication ports.....	33

6.2 Intelligent Card (Optional)	34
6.3 UPS Management Software	34
7. UPS maintenance	35
7.1 Equipment care.....	35
7.2 Transporting the UPS	35
7.3 Storing the equipment.....	35
7.4 Replacing batteries	36
7.5 Recycling the used equipment	37
8. Troubleshooting	38
8.1 Typical alarms and faults.....	38
8.2 Silencing the alarm.....	42
9. Specifications	43
9.1 Model specifications.....	43
10 Glossary	47

1. Introduction

Thank you for selecting UPS to protect your electrical equipment. The UPS has been designed with the utmost care.

We recommend that you take the time to read this manual to take full advantage of the many features of your UPS (Uninterruptible Power System).

Before installing your UPS, please read the booklet presenting the safety instructions. Then follow the indications in this manual.

1.1 Environmental protection

Products are developed according to an eco-design approach.


Substances

This product does not contain CFCs, HCFCs or asbestos.

Packing

To improve waste treatment and facilitate recycling, separate the various packing components.

- The cardboard we use comprises over 50% of recycled cardboard.
- Sacks and bags are made of polyethylene.
- Packing materials are recyclable and bear the appropriate identification symbol

Materials	Abbreviations	Number in the symbols	
Polyethylene terephthalat	PET	01	
High-density polyethylene	HDPE	02	
Polyvinyl chloride	PVC	03	
Low-density polyethylene	LDPE	04	
Polypropylene	PP	05	
Polystyrene	PS	06	

Follow all local regulations for the disposal of packing materials.

Product

The product is made up of recyclable materials.

Dismantling and destruction must take place in compliance with all local regulations concerning waste. At the end of its service life, the product must be transported to a processing center for electrical and electronic waste.

Battery

The product contains lead-acid batteries that must be processed according to applicable local regulations concerning batteries.

The battery may be removed to comply with regulations and in view of correct disposal.

1.2 Electronic equipment protection

The uninterruptible power system (UPS) protects your sensitive electronic equipment from the most common power problems, including power failures, power sags, power surges, brownouts, line noise, high voltage spikes, frequency variations, switching transients, and harmonic distortion.


Power outages may occur unexpected, and the power quality will be erratic. These power problems have the potential to corrupt critical data, destroy unsaved work sessions, and damage hardware - causing hours of lost productivity and expensive repairs.

With the UPS, you can safely eliminate the effects of power disturbances and guard the integrity of your equipment. Providing outstanding performance and reliability, UPS's unique benefits include:


- True online double-conversion technology with high power density, utility frequency independence, and generator compatibility.
- Selectable High Efficiency mode of operation.
- Standard communication options: one RS232 communication port, one USB communication port, one dry in port and dry out port.
- Optional connectivity cards with enhanced communication capabilities.
- Firmware that is easily upgradable without a service call.

2. Presentation

2.1 RT Front panel




2.2 RT Rear panels




- | | |
|--|---|
| 1. Intelligent slot | bat-, and no external battery connector #10.) |
| 2. USB | 9. Input switch |
| 3. RS232 | 10. External battery connector |
| 4. RJ11 (only for RT model) | 11. Maintenance bypass switch
(optional) |
| 5. EPO | 12. EBM connector |
| 6. Parallel card (optional) | |
| 7. Dry IN/OUT | |
| 8. Input /Output terminal
(Standard model 5pole, IPL, IPN, PE,OPL,
OPN; long backup model has 2 version, one
is 5 Pole. Another is 7pole. 7pole add bat+, | |

2.3 EBM Front panel:



2.4 EBM rear panel:




13. Fuse board cover (replace EBM fuse)

14. EBM plug

15. EBM connector

2.3 Circuit diagram



3. Installation

It is recommended to move the equipment to the installation site by using a pallet jack or a truck before unpacking.

The system may be installed only by qualified electricians in accordance with applicable safety regulations.

The cabinet is heavy, please install it with at least two peoples.

3.1 Inspecting the equipment

If any equipment has been damaged during shipment, keep the shipping cartons and packing materials for the carrier or place of purchase and file a claim for shipping damage. If you discover damage after acceptance, file a claim for concealed damage.



3.2 Unpacking the Unit





Unpacking the unit in a low-temperature environment may cause condensation occurred in and on the cabinet. Do not install the unit until the inside and outside of the unit are absolutely dry (hazard of electric shock).

Remove the packing materials and lift the unit out with two people at least.

◆ RT UPS



◆ RT EBM



Note:

The cabinet is heavy, please see spec weight provided on the carton/label.

Do not lift the unit's front panel and rear panel.

Discard or recycle the packaging in a responsible manner, or store it for future use.



Packing materials must be disposed in compliance with all local regulations concerning waste. Recycling symbols are printed on the packing materials to facilitate sorting.

3.3 Checking the accessory kit

Verify that the following additional items are included with the unit:

	Eaton DX RT UPS 6000VAIN/10000VAIN	Eaton DX RT UPS 6000VAXLIN/10000VAXLIN	DXRT EBM
Battery power cable			*
USB cable	V	V	
RS232 cable	O	O	
Parallel cable	O	O	
Dry contractor	V	V	
EPO contractor	*	*	
Stabilizer bracket	V	V	
Extension plate of Stabilizer bracket			V
Ear bracket	V	V	V
Rail kit		O	O
User manual	V	V	V

V: standard configuration

*: assembled to unit

O: optional configuration

If you ordered other accessories, please contact with local sale center.

3.4 Install the unit

3.4.1 RT model:

Rack position installing


This procedure is suitable for 19 inch rack cabinet installation with a minimum of 800mm depth.

◆ UPS model

Identify the final position and keep '2U' space for this installing.

Note that you already installed a 'rail kit' to rack cabinet for this operation, and '1U' rail kit is recommended to be selected.

1. Install 'Ear bracket' to the unit by the M4 screws (flat head).
2. Slide the unit into 'rail kit' and make sure tighten the 'rack mounting screw'.




◆ EBM model


Identify the final position and keep '3U' space for this installing, and it is recommended to be installed below to UPS.

Note that you already installed a 'rail kit' to rack cabinet for this operation, and '2U' rail kit is recommended to be selected.

1. Install 'Ear bracket' to the unit by the M4 screws(flat head).
2. Slide the unit into 'rail kit' and make sure tighten the 'rack mounting screw'.



3. Connect EBM to UPS with 'Battery power cable'.




Note:

This 'Battery power cable' may have different plug according to the number of battery inside of this unit, please check the 'Voltage ' parameter on rear-panel if it matches the UPS before connection.

The battery number can be adjusted from '16pcs*1 strings' to '20pcs*1 strings' for this unit, if you ordered other type EBM, please contact with local sale center.

If installing additional unit, place it next to the previous unit in their final location.

4. UPS external battery (1.8 meters long).




Note:

Before connecting the battery, please refer the wiring label "+", "-", and "G" .


Tower position installing

◆ **UPS model**

1. Rotate the LCD model to tower direction.




2. Set up the 'Stabilizer bracket', then take the unit into 'Stabilizer bracket'.



◆ **EBM model**

1. Set up the 'Extension plate' as below and install to 'Stabilizer bracket' from UPS.
2. Take the UPS& EBM into 'Stabilizer bracket' individually.
3. Connect to UPS with 'Battery power cable'--- Refer to rack position installing.



Note:

This unit is recommended to be installed to UPS's right side.


If installing additional unit, place it next to the previous unit in their final location.

4. Power cables connection

Recommended protective devices and cable cross-sections

Recommended upstream protection

UPS power rating	Upstream circuit breaker
DX RT 6K UPS	D curve – 63A
DX RT 10K UPS	D curve – 100A




Read the Safety instructions page 3 regarding backfeed protection requirements.

Recommended cable cross-sections

Model	DX RT 6K UPS	DX RT 10K UPS
Protective earthing conductor Min cross section	6mm ² (8AWG)	10mm ² (6AWG)
Input L, N, G Min conductor cross section	6mm ² (8AWG)	10mm ² (6AWG)
Input fuse	80A	100A
Output L,N, Min conductor cross section	6mm ² (8AWG)	10mm ² (6AWG)



It is recommended that an external isolating device should be installed between the mains input and UPS as shown in Figure



AC Contactor: 208-240V, 63A (RT 6 kVA) 208-240V, 100A (RT 10 kVA)

4.1 Access to terminal blocks (AC source to UPS)



High leakage current:

Earth connection essential before connecting supply.

Common input/output sources connection




This type of connection must be carried out by qualified electrical personnel

Before carrying out any connection, check that the upstream protection devices (Normal AC source and Bypass AC source) are open "O" (Off).


Always connect the ground wire first

1. Remove the cover of terminal block.



2. Connect the AC cable to terminal blocks refer to the indication on rear panel


◆ R/T model:



3. Tie up the AC cable to the rear panel.

4. Install back the cover of terminal block.


4.2 Access to terminal blocks (PDU source to R/T UPS)(Optional)



If you ordered PDU model, please connect the UPS's terminal blocks from PDU's source, detail operation please refer to PDU's user manual.


4.3 Parallel Installation and Operation (Optional)

As long as the UPS is equipped with parallel board and parallel cables, up to 3 UPSs can be connected in parallel to configure a sharing and redundant output power.




How to install a new parallel UPS system:

- 1) Before installing a new parallel UPS system, please prepare the input /output wires, breakers, and a main maintenance mechanical switch or static switch.
- 2) Independent battery packs for each UPS.
- 3) Remove the cover plate of parallel port on the UPS, connect each UPS one by one with parallel cable, and make sure the cable is screwed tightly.






- 4) Install 'cable locker' to protect the 'parallel cable' for each UPS.



- 5) Connect the input and output wires and make sure all the breakers are turned off.

◆ Rack model:





- 6) Turn on the input breakers for the parallel UPS.
- 7) Pressing  button continuously for more than 1 second for one UPS of the system, then the system will turn to line mode.
- 8) Regulate the output voltage of the each UPS separately, and check if the difference of output voltage is less than 0.5V among the parallel system. If the difference is more than 0.5V, the UPS need to be regulated.
- 9) If the difference output voltage is less than 0.5V, turn off the input breakers to let UPS shut down. And then switch on the output breakers for all the UPS.
- 10) Switch on the input breakers for the parallel UPS. Pressing  button continuously more than 1 second for one UPS of the system, then the system will turn to line mode, after these operations, the system will work normally in parallel mode.

Note: The output wiring requirement as below:



- 1) If the distance between the UPS and breaker panel is less than 20 meters in parallel system, the length difference between input and output cable of the UPSs is required to be less than 20%.
- 2) If the distance between the UPS and breaker panel is more than 20 meters in parallel system, the length difference between input and output cable of the UPSs is required to be less than 5%.

2. How to join a new UPS to parallel system:


- 1) Firstly, a main maintenance mechanical switch or static switch should be installed for the parallel system.

- 2) Regulate the output voltage of the new UPS: check if the output voltage difference between the new UPS and the parallel system is less than 0.5V.
- 3) Ensure the bypass of the parallel system is normal and the auto bypass setting is “enable”, then press the  button to turn off the UPS, the UPS will turn to bypass mode.
- 4) Set the main maintenance switch or static switch from “UPS” to “BPS”, then switch off the main output breaker, input breaker and mains breaker, then the UPS will shut down.
- 5) Connect the cable and wire for the new ups.
- 6) Switch on the input breakers and mains breaker, and make sure that every UPS work in bypass mode.
- 7) Switch on the O/P breakers and main O/P breaker, transfer the main maintenance switch or static switch from “BPS” to “UPS”.
- 8) Press the  button of one UPS, all the ups will turn on, after that, the system will work in Line mode.

3. How to remove a single UPS from parallel system:

- 1) Firstly, a main maintenance mechanical switch or static switch should be installed for the parallel system.
- 2) Ensure the bypass is normal and the auto bypass setting is “enable”, press the  button to turn off the UPS system, and the UPS system will turn to bypass mode.
- 3) Transfer the main maintenance switch or static switch from “UPS” to “BPS”, then switch off the output breakers, input breakers and mains breaker in the parallel system, and the UPS will shut down.
- 4) Switch off the main O/P breaker and O/P breaker in the parallel system.
- 5) Remove the wanted UPS and disconnect cables/wires.
- 6) Switch on the mains breaker and input breaker of the reserved UPS, make sure the UPS work in bypass mode.
- 7) Switch on the O/P breaker and main O/P breaker.
- 8) Transfer the main maintenance switch or static switch from “BPS” to “UPS”, and press the  button to turn on the UPS, and the UPS will turn on to Line mode.


3. How to remove all the UPS from parallel system:

- 1) Firstly, a main maintenance mechanical switch or static switch should be installed for the parallel system.
- 2) Ensure the bypass is normal and the auto bypass setting is "enable", press the  button to turn off the UPS system, and the UPS system will turn to bypass mode.
- 3) Transfer the main maintenance switch or static switch from "UPS" to "BPS", then switch off the output breakers, input breakers and mains breaker in the parallel system, and the UPS will shut down. The line will power the load via maintenance mechanical switch or static.

5. Operation

5.1 Control panel






The UPS has a graphical LCD with five-button. It provides useful information about the UPS itself, load status, events, measurements and settings.



The following table shows the indicator status and description:

Indicator	Status	Description
Online model (Green)	On	The UPS is operating normally on Online or on High Efficiency mode.
Bat model (Orange)	On	The UPS is on Battery mode.
Bypass model (Orange)	On	The UPS is on Bypass mode.
	Flash	The UPS is on Standby mode.
Fault (Red)	On	The UPS has an active alarm or fault.

The following table shows the Control Button Functions:


The Button	Function	Illustration
	Power on	Press this button for >100ms&<1s can power on the ups without utility input at the condition of battery connected.
	Turn on	When the unit is powered on and stayed is in Bypass mode, press this button for >1s can turn on the UPS.
	Turn off	Press this button >3s can turn off the UPS.
	Clear fault	When the unit is in fault mode, press this button for >1s to stop alarm and clear fault
	Scroll up	Press this button for >100ms&<1s to scroll up the menu option
	Scroll down	Press this button for >100ms&<1s to scroll down the menu option
	Enter next menu tree	Press this button for >100ms&<1s to select the present menu option, or enter next menu, but do not change any setting
	Select one menu option	Press this button for >100ms&<1s to select the present menu option, or enter next menu, but do not change any setting
	Confirm the present setting	Press this button for >1s to confirm the edited options and change the setting
	Exit main menu	Press this button for > 100ms & < 2s to exit the present menu to default system status display menu or the higher level menu without executing a command or changing a setting
	Mute buzzer	Press this button for > 2s to mute the buzzer temporarily, once new warning /fault is active or UPS reenters into bypass mode or battery mode, buzzer will work again.

The Buzzer definition as below:

UPS condition	Buzzer status
Fault active	Continuous
Over Load Warning active	2 Beep every second
Other Warning active	Beep every second
Battery output	Beep every 4 seconds, if battery low, buzzer Beep every second
Bypass output	Beep every 2 minutes






5.2 LCD description





The LCD backlight automatically dims after 2 minutes of inactivity (except UPS is fault). Press any button to wake up the screen.






The following table describes the information of ups status.

Note: If other indicator appears, see troubleshooting on chapter 7.2 for more information.

Operation status	Cause	Description
Standby mode 	The UPS is Off.	UPS is operating without output.
Online mode 	The UPS is operating normally.	The UPS is powering and protecting the equipment.
Battery mode  1 beep every 4 seconds	A utility failure has occurred and the UPS is on Battery mode.	The UPS is powering the equipment with the battery power. Prepare your equipment for shutdown.
High Efficiency mode 	The UPS is operating on High Efficiency mode.	Once the mains are loss or abnormal, the UPS would transfer to Line mode or Battery mode and the load is supplied continuously. 1. The function could be enabled through the LCD setting or the software (Winpower, etc.) 2. It is reminded that the transfer time of UPS output from HE mode to battery mode is about 10ms. But it is still too long for some sensitive load.
Bypass mode 	Overload or fault has occurred, or a command has been received, and the UPS is in Bypass	Equipment is powered but not protected by the UPS.

<p>Warning</p> 	<p>There are some abnormal problems during the operation of UPS. Normally the problems are not fatal</p>	<p>The UPS continues working, but please pay attention to the warning, or the UPS may fail.</p>
<p>Fault</p> 	<p>Some fatal problems happened</p>	<p>The UPS will cut off the output or transfer to bypass mode at once, and keep alarming.</p>
<p>Overload</p> 	<p>The load exceeds the capacity of the UPS</p>	<p>Some unnecessary loads should be cut off one by one to reduce the load connected to the UPS.</p>
<p>No Battery</p> 	<p>UPS battery is not connected, please check the line</p>	<p>Once the mains are loss or abnormal , The UPS will shut down abnormally and the output device will lose its protection.</p>

5.3 Display functions

Use the two middle buttons ( and ) to scroll through the menu structure. Press the Enter () button to select an option. Press the ESC button to cancel or return to the previous menu.

When starting the UPS, the display is in the default UPS status summary screen.

Main menu	Submenu	Display information or Menu function
UPS status		[status summary screen] / [Alarm] / [Battery charging/Volt/level/remaining time] / [mode/ Para Num. /Running time]
Measurements		[Load] W VA/ [Output/Current] A % / [Output/Voltage] V Hz/ [Input/Voltage] V Hz / [Battery] V % / [DC bus] V V / [temperature] °C [Battery remaining time]Min
Control	Single UPS battery test	Starts a manual battery test for single UPS
	Parallel UPS battery test	Starts a manual battery test for parallel UPS
	Single UPS turn off	Turn off one UPS in parallel UPS system

	Reset fault status	Clears active fault
	Clear event log	Clears events
	Restore factory set	Returns all settings to original values
Settings		Sets parameters
Event log		Event list
Identification		[Product type/model] / [Part/Serial number] / [UPS/NMC firmware]

5.4 User settings

The following table displays the options that can be changed by the user.

Submenu	Available settings	Default settings
Password	Key the password	USER
language	[English][Deutsch][Español]	English
User password	[disabled] [Enabled]	[disabled]
Audible alarm	[enabled] [disabled]	[enabled]
Output voltage	[208V] [220V] [230V] [240V] Can be changed in Standby mode and Bypass mode	[230V]
Output frequency	[autosensing] [50HZ][60HZ]	[autosensing]
Power strategy	[normal] [high efficiency] [converter]	[normal]
Auto bypass	[enabled] [disabled]	[enabled]
Auto restart	[enabled] [disabled] Authorize the product to restart automatically when mains recovers after a complete battery discharge.	[enabled]
Dry in	[Disabled] [SON] [SOFF] [Maintain bypass]	[Disabled]
Dry out	[Load powered] [On battery mode] [Battery low] [Battery disconnected] [Bypass output] [UPS normal]	[Load powered]
Start on battery	[enabled] [disabled]	[enabled]

External battery modules	[0~20]	According to model
External battery AH setting	[0~300]	According to model
Battery remaining time	[enabled] [disabled]	[enabled]
Charger current	[0~4] 0~4A for standard model [0~12] 0~12A for long backup model	[1.4A] for 6K [2A] for 10K [4A] for 6KS/10KS
Site wiring fault alarm	[disabled] [enabled]	[disabled]
LCD contrast	[-5 ~ +5]	[+0]

5.5 UPS startup and shutdown



Please make sure there is no load connected to the ups before the ups is turned on, and take on the load one by one after the UPS is turned on.

Take off all of the connected loads before turning off the UPS.

Starting the UPS with utility




Verify that the total equipment ratings do not exceed the UPS capacity to prevent an overload alarm.

Start the UPS with utility:

Check all the connection is correct.

Power on the UPS, the fan begins to rotate. After that, the LCD will show the default UPS status summary screen.


Pressing  button continuously for more than 1 second, the buzzer will beep 300ms, UPS starts to turn on.

A few seconds later, the UPS turns into Line mode. If the utility power is abnormal, the UPS will transfer to Battery mode without output interruption of the UPS.

Starting the UPS on Battery




Before using this feature, the UPS must have been powered by utility power with output enabled at least once.


After connect the UPS with battery, should wait 10s before pressing the  button for pre-charging the auxiliary power supply.

Battery start can be disabled. See “Start on battery” setting in user settings-refer to chapter 5.4.

To start the UPS on battery:

Check all the connection is correct.


Pressing  button continuously for more than 100ms, the UPS would be powered on. At this time the fan begins to rotate. Then LCD will show the default UPS status summary screen.

Pressing  button continuously for more than 1 second, the buzzer will beep for 300ms, UPS starts to turn on.

A few seconds later, the UPS turns into Battery mode. If the utility power comes back, the UPS will transfer to Line mode without output interruption of the UPS.

UPS shutdown with utility


To shut down the UPS with utility:

Pressing  button continuously for more than 3 seconds and the buzzer will beep 300ms. After that, the UPS will turn into Bypass mode at once.

When completing the above action, UPS output voltage is still present. In order to cut off the UPS output, simply cut off the utility power supply. A few seconds later, the ups will shut down and no output voltage is available from the UPS output terminal.

UPS shutdown without utility

To shut down the UPS without utility:



To power off the UPS by pressing  button continuously for more than 3 second, and the buzzer will beep for 300ms. The UPS will cut off the output at once.

A few seconds later, the ups will shut down and no voltage is available from the UPS output.

5.6 LCD operation


Except the default UPS status summary screen, the user can get more useful information about UPS status, detailed various measurements, previous event records which ever occurred, UPS own identification, and could change the settings to fit the user own requirements, optimize the function of UPS.

The main menu

In the default UPS status summary screen, when pressing  or  <300ms, the detailed information about alarm, battery, the system status would be shown.

In the default UPS status summary screen, when pressing ESC >300ms, the display would enter main menu tree.

The main menu tree includes six branches: UPS status menu, measurement menu, event log menu, control menu, identification menu and settings menu.




The UPS status menu

By pressing **⏪** on the menu of “UPS status”, the display would enter the next UPS status menu tree.

The content of UPS status menu tree is same as the default UPS status summary menu.

By pressing ESC >300ms, the display would return the last main menu tree.




The measurement menu


By pressing **←** on the menu of "Measurement", the display would enter the next measurement menu tree.



A lot of detailed useful information could be checked here, Ex. the output voltage and frequency, the output current, the load capacity, the input voltage and frequency, etc.

By pressing ESC >300ms, the display will return to the last main menu tree.




The event log menu

By pressing  on the menu of “Event log”, the display would enter the next event menu tree.


All the previous events, alarm and fault have been recorded here. The information includes the illustration, the event code, and the precise time of UPS when the event happened. By press  or  <300ms, all the events could be displayed one by one.

The max number of record is 100, when the number is larger than 100, the latest will replace the previous.

By pressing ESC >300ms, the display would return the last main menu tree.




The control menu

By pressing  on the menu of “Control”, the display would enter the next control menu tree.


Start Battery Test: this is one command that control the UPS to do the battery test.

Reset Fault status: when fault occurs, UPS would keep in Fault mode and alarm. To recover to normal status, enter this menu to reset error status, then UPS

would stop alarm and recover to bypass mode. And the reason of fault should be checked and deleted before UPS is turned on again by manual operation.
 Restore factory settings: all the settings would be recover to default factory settings. It could only be done in Bypass mode.




The identification menu

By press  on the menu of “Identification”, the display would enter the next identification menu tree.

The identification information includes UPS serial number, firmware serial number, model type, would be shown here.

By press ESC >300ms, the display would return the last main menu tree.




The setting menu



Please contact your local distributor for further information before using the settings. Some settings would be changed the specification, and some settings would enable or disable some functions. The unsuitable option setting by user may result in potential failures or protecting function loss, even directly damage the load, battery or UPS.


AH setting could be set via RS232 or USB communication. Default AH setting is disabled.

Most of settings could only be done while UPS is in Bypass mode.



Example: set rated output voltage value

Setting menu tree



6. Communication


6.1 Communication ports

RS232 or USB communication ports




The RS232 and USB communication ports cannot operate simultaneously.

1. Communication cable to the serial or USB port on the computer.
2. Connect the other end of the communication cable to the RS232 or USB communication port on the UPS.



Emergency Power Off

The Emergency Power Off interface provides an emergency power off function. When the EPO function is enabled (default setting), once the EPO port is pulled out, the UPS would shut off the output and enter into EPO mode, and the UPS would not respond anything ON/OFF request unless the port is plugged back.



Dry in & Dry out

Dry in allows remote action to switch On/ switch Off/ maintain bypass the UPS. When contact changes from closed to open, the UPS is switch On/ switch Off/ maintain bypass the UPS.

The Dry out port is normally closed, if the Dry out port is open, it indicate that the UPS is Loaded power/ On battery mode /Battery low /Battery disconnected /Bypass output/ups normal.


6.2 Intelligent Card (Optional)

Intelligent Card allow the UPS to communicate with different types of devices in variety of networking environments. The Online series has one available communication bay for the following connectivity cards:

1. Connect UPS-MS Web/SNMP Card – has SNMP and HTTP capabilities as well as monitoring through a Web browser interface; connects to a twisted-pair Ethernet (10/100BaseT) network. In addition.
2. MODBUS card provides connection to Modbus protocol with standard RS485 signal. To see more detail please check the MODBUS user manual.
3. This series UPS has AS400 card (an optional accessory) for AS400 communication protocol. Please contact your local distributor for details.

6.3 UPS Management Software

WinPower is a new software for UPS monitoring, which provides user-friendly interface to monitor and control your UPS. This unique software provides safely auto shutdown for multi-computer systems while power failure. With this software, users can monitor and control any UPS on the same LAN no matter how far from the UPSs.



Installation procedure:

1. Go to the website:

<http://www.ups-software-download.com/>

2. Choose the operation system you need and follow the instruction described on the website to download the software.

3. When downloading all required files from the internet, enter the serial No: 511C1-01220-0100-478DF2A to install the software.

When you finish installation, restart your computer, the WinPower software will appear as a green plug icon located in the system tray, near the clock.

7. UPS maintenance

7.1 Equipment care

For the best preventive maintenance, keep the area around the equipment clean and dust free. If the atmosphere is very dusty, clean the outside of the system with a vacuum cleaner.

For full battery life, keep the equipment at an ambient temperature of 25°C (77°F).



If the UPS requires any type of transportation, verify that the UPS is disconnected and turned off. The batteries are rated for a 3-5 year service life. The length of service life varies, depending on the frequency of usage and ambient temperature. Batteries used beyond expected service life will often have severely reduced runtimes. Replace batteries at least every 4 years to keep units running at peak efficiency.

7.2 Transporting the UPS



Please transport the UPS only in the original packaging (to protect against shock and impact).

7.3 Storing the equipment

If you store the equipment for a long period, recharge the battery every 6 months by connecting the UPS to utility power. The EBM charge to 90% capacity in less than 3 hours.

However, recommends that the batteries charge for 48 hours after long-term storage.

If the date has passed and the batteries were never recharged, do not use them. Contact your service representative.

7.4 Replacing batteries



DO NOT DISCONNECT the batteries while the UPS is in Battery mode.



Consider all warnings, cautions, and notes before replacing batteries.

- Servicing should be performed by qualified service personnel with knowledgeable of batteries and required precautions. Keep unauthorized personnel away from batteries.
- Batteries can present a risk of electrical shock or burn from high short circuit current. Observe the following precautions:
 1. Remove watches, rings, or other metal objects,
 2. Use tools with insulated handles,
 3. Do not lay tools or metal parts on top of batteries,
 4. Wear rubber gloves and boots.
- When replacing batteries, replace with the same type and number of batteries or battery packs. Contact your service representative to order new batteries.
- Proper disposal of batteries is required. Refer to your local codes for disposal requirements.
- Never dispose of batteries in a fire. Batteries may explode when exposed to flame.
- Do not open or mutilate the battery or batteries. Released electrolyte is harmful to the skin and eyes and may be extremely toxic.
- Take care if the battery is inadvertently grounded. If grounded, remove source from ground. Contact with any part of a grounded battery may cause electrical shock.
- The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).
- **ELECTRIC ENERGY HAZARD.** Do not attempt to alter any battery wiring or connectors. It may cause injury.
- Please disconnect battery charging source before battery replacing or maintenance.

Replacing the EBM(s)



The EBM is heavy. Lifting the cabinet into a rack requires two people at

least.

For Tower module, should turn the MBS to bypass and switch off the input and then replace the EBM(s).

For RT module, if PDU is connected with the UPS, should turn the MBS to bypass and switch off the input and then replace the EBM(s). If PDU is not connected with the UPS, should turn off the UPS and then replace the EBM.

To replace the EBM(s):

1. Unplug the EBM power cable from the UPS.

If additional EBM(s) are installed, unplug the EBM power cable from each EBM.

2. Replace the EBM(s). See "Recycling the used equipment" refer to chapter 7.5 for proper disposal.




A small amount of arcing may occur when connecting the EBM to UPS. This is normal and will not harm personnel. Please connect the EBM cable to the UPS quickly and firmly.

3. Plug the EBM cable(s) into the battery connector(s).

4. Verify that the EBM connections are tight, and there are adequate bend radius and strain relief exist for each cable.


Testing new batteries

1. Charge the batteries for 48 hours.

2. By pressing  on the menu of "Control".

3. Select Control then Single battery test.

The UPS can starts battery test only in line mode without active alarms.

During the battery test, the UPS transfers to Battery mode and discharges the batteries for 10 seconds. The front panel displays  and the percentage of the test completed.

7.5 Recycling the used equipment



Contact your local recycling or hazardous waste center for information on proper disposal of the used equipment.

Do not dispose of the batteries in the fire. Which may cause battery explosion. The batteries must be rightly disposed according to local regulation.

Do not open or destroy the batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.



Do not discard the UPS or the UPS batteries in the trash. This product contains sealed, lead acid batteries and must be disposed of properly. For more information, contact your local recycling/ reuse or hazardous waste center.



Do not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.

8. Troubleshooting


The UPS is designed for durable, automatic operation and also alert you whenever potential operating problems may occur. Usually the alarms shown by the control panel do not mean that the output power is affected. Instead, they are preventive alarms intended to alert the user.

- Events are silent status information that are recorded into the Event log. Example = "Battery charging".
- Alarms are recorded into the Event log and displayed on the LCD status screen with the logo blinking. Some alarms may be announced by a beep every 1 second. Example = "Battery low".
- Faults are announced by a continuous beep and red LED, recorded into the Event log. Example = Out. short circuit.

Use the following troubleshooting chart to determine the UPS alarm condition.

8.1 Typical alarms and faults

To check the Event log:

1. By pressing  on the menu of "Event log".
2. Scroll through the listed events or faults.
3. The following table describes typical conditions.

Conditions	Possible cause	Action
Fault code: A107 Fault light flashes, 1 beep every 1 second.	Input L, N line reversed	Check the input connection
	The chassis is not grounded	

Fault code: A60D Fault light flashes, 1 beep every 1 second.	Battery not connected	Check the battery and battery cable. If the battery is damaged, Replace it immediately by a professional.
Fault code: A604 Fault light flashes, 1 beep every 1 second.	Battery voltage is too low	Check the battery, If the battery is damaged, Replace it immediately by a professional.
Fault code: A502 Fault light flashes, 1 beep every 1 second.	Battery voltage is too high	Check the battery and charger, If the battery is damaged, Replace it immediately by a professional.
Fault code: A500 Fault light flashes, 1 beep every 1 second.	UPS charger fault	Please contact your supplier
Fault code: A503 Fault light flashes, 1 beep every 1 second.	UPS charger fault , Output voltage is too low.	Please contact your supplier
Fault code: F613 Fault lamp lights long, Beep continuous.	Indicates that the battery quantity is incorrect.	Please contact your supplier
Fault code: F300 Fault lamp lights long, Beep continuous.	Indicates that the UPS get positive BUS over voltage fault.	Please contact your supplier
Fault code: F301 Fault lamp lights long, Beep continuous.	Indicates that the UPS get negative BUS over voltage fault.	Please contact your supplier
Fault code: F302 Fault lamp lights long, Beep continuous.	Indicates that the UPS get positive BUS under voltage fault	Please contact your supplier
Fault code: F303 Fault lamp lights long, Beep continuous.	Indicates that the UPS get negative BUS under voltage fault	Please contact your supplier

Fault code: F304 Fault lamp lights long, Beep continuous.	Indicates that the positive BUS voltage and negative BUS voltage unbalance to fault	Please contact your supplier
Fault code: F304 Fault lamp lights long, Beep continuous.	Indicates that the positive BUS and negative BUS Short fault	Please contact your supplier
Fault code: F305 Fault lamp lights long, Beep continuous.	Indicates that the UPS rectifier fault.	Please contact your supplier
Fault code: A307 Fault lamp lights long, Beep continuous.	Indicates that the UPS rectifier fuse fault.	Please contact your supplier
Fault code: F805 Fault lamp lights long, Beep continuous.	Indicates that the UPS has detected abnormally low impedance placed on its output and considers it a short circuit	Remove all the loads. Turn off the UPS. Check if UPS output and loads is short circuit. Ensure short circuit is removed before turning on again.
Fault code: F70D Fault lamp lights long, Beep continuous.	Indicates that the UPS get invert over voltage fault	Remove some equipment from the UPS, clear the fault code and try restart again.
Fault code: F70C Fault lamp lights long, Beep continuous.	Indicates that the UPS get inverter under voltage fault	Remove some equipment from the UPS, clear the fault code and try restart again.
Fault code: F704 Fault lamp lights long, Beep continuous.	Indicates that the UPS inverter fault	Please contact your supplier

<p>Fault code: A80E Fault LED is flash 2 beep every 1 second</p>	<p>Power requirements exceed the UPS capacity</p>	<p>Remove some of the equipment from the UPS. The UPS continues to operate, but may switch to Bypass mode or shut down if the load increases. The alarm resets when the condition becomes inactive.</p>
<p>Fault code: A810 Fault LED is flash 2 beep every 1 second</p>	<p>Overload fault</p>	<p>Remove some of the equipment from the UPS. Check if it is fault for the equipment.</p>
<p>Fault code: F808 Fault lamp lights long, Beep continuous.</p>	<p>UPS has transferred to bypass or fault mode because of overload in inverter mode</p>	<p>The UPS transfers to Battery mode if supporting the load. Remove some of the equipment from the UPS</p>
<p>Fault code: F208 Fault lamp lights long, Beep continuous.</p>	<p>UPS has cut off the output and transferred to fault mode because of overload in bypass mode</p>	<p>Remove some of the equipment from the UPS</p>
<p>Fault code: A900 Fault LED is flash 1 beep every 1 second</p>	<p>An overload or a fault has occurred, or a command has been received and the UPS is in Bypass mode</p>	<p>Please contact your supplier</p>
<p>Fault code: F806 Fault lamp lights long, Beep continuous.</p>	<p>Shut down in emergency</p>	<p>Please check EPO terminal status.</p>
<p>Fault code: F004 Fault lamp lights long, Beep continuous.</p>	<p>The UPS internal heat sink temperature is too high or a fan has failed. At the warning level, the UPS generates the alarm but remains in the current operating state. If the temperature rises another 2°C, the UPS transfers to Bypass mode or Standby mode.</p>	<p>Clear vents and remove any heat sources. Allow the UPS to cool. Ensure the airflow around the UPS is not restricted. Restart the UPS. If the condition continues to persist, contact your service representative.</p>

Fault code: A004 Fault LED is flash 1 beep every 1 second	Alarm because of UPS internal heat sink temperature is too high.	Please contact your supplier
Fault code: A004 Fault LED is flash 1 beep every 1 second	Alarm because of ambient temperature high.	Check if the ambient temperature exceed 50°C. if it is normal, please contact your supplier
Fault code: A007 Fault LED is flash 1 beep every 1 second	Fans blocked	Please contact your supplier
Fault code: F207 Fault lamp lights long, Beep continuous.	Bypass fault	Please contact your supplier
Fault code: A00E Fault LED is flash 1 beep every 1 second	In parallel system, parallel cable disconnect	Check if the parallel cable connect OK.
Fault code: A012, AC18 Fault LED is flash 1 beep every 1 second	Parallel system, UPS1 line ok, UPS2 line loss	Check the line input
Fault code: A00F, AC19 Fault LED is flash 1 beep every 1 second	Parallel system, UPS mode (normal, converter, HE) different	Check UPS OP mode, Keep OP mode be the same
Fault code: F811 Fault lamp lights long, Beep continuous.	Negative output power	Please contact your supplier
Fault code: F00E Fault lamp lights long, Beep continuous.	parallel cable disconnect	Check if the parallel cable connect OK.

8.2 Silencing the alarm

Press the ESC (Escape) button 3s on the front panel display to silence the alarm. Check the alarm condition and perform the applicable action to resolve the condition. If the alarm status changes or press the ESC button 3s on the front panel display, the alarm beeps again, overriding the previous alarm silencing.

9. Specifications

9.1 Model specifications

Table 1. Power Module model list

	Power Ratings
Eaton DX RT 6000VAIN	6000VA / 6000W
Eaton DX RT 6000VAXLIN	6000VA / 6000W
Eaton DX RT 10000VAIN	10000VA / 10000W
Eaton DX RT 10000VAXLIN	10000VA / 10000W

Note: 1. 6000VAIN/10000VAIN means standard model
 2. 6000VAXLIN/10000VAXLIN means long backup model

Table 2. Extended Battery Module model list

Model	Configuration	Battery voltage	For power ratings
Eaton DXRT EBM 192-07 RT3U IN	RT	192Vdc (7Ah)	6000-10000VA
Eaton DXRT EBM 192-09 RT3U IN	RT	192Vdc (9Ah)	6000-10000VA

Table 3. Weights and dimensions

Description	Weights (kg)	Dimensions (mm) W x H x D
Eaton DX RT 6000VAIN	13.3	438*86.3*573
Eaton DX RT 6000VAXLIN	13.6	438*86.3*573
Eaton DX RT 10000VAIN	15.2	438*86.3*573
Eaton DX RT 10000VAXLIN	15.5	438*86.3*573
Eaton DXRT EBM 192-07 RT3U IN	46	438*129*593
Eaton DXRT EBM 192-09 RT3U IN	52	438*129*593

Note: The weight in this table is reference only, please see the labels on the carton for details

Table 4. Electrical input

Nominal frequency	50/60Hz auto-sensing
Frequency range	40 Hz– 70 Hz ≤60% rated load 45Hz– 55Hz(50Hz system) 54Hz– 66Hz(60Hz system) >60% rated load

	45Hz– 55Hz 54Hz– 66Hz >60% rated load
Bypass voltage range	176~276Vac
Noise filtering	MOV for normal and common mode noise

Model	Default input (Voltage/Current)	Voltage at 100% Load
Eaton DX RT 6000VAIN	230V/31.2A	176~276Vac
Eaton DX RT 6000VAXLIN	230V/38.7A	176~276Vac
Eaton DX RT 10000VAIN	230V/49.9A	176~276Vac
Eaton DX RT 10000VAXLIN	230V/57.6A	176~276Vac

Table 5. Electrical input connectionsk

Model	Input connection	Input cable
Eaton DX RT 6000VAIN	Hardwired	Not provided
Eaton DX RT 6000VAXLIN		
Eaton DX RT 10000VAIN		
Eaton DX RT 10000VAXLIN		

Table 6. Electrical output

All models	Normal mode	Battery mode
Voltage regulation	±1%	±1%
Efficiency	> 98% (High Efficiency mode) > 95%	> 93%
Frequency regulation	50Hz±0.1Hz	50Hz±0.1Hz
Nominal output	208*, 220V, 230V, 240V(voltage configurable) 6000/10000VA* 6000/10000W*	
Frequency	50 or 60Hz, autosensing or configurable as a frequency converter	
Output overload	100-105% : no alarm 105-125% : load transfers to Bypass mode after 10 minutes 125-150% : load transfers to Bypass mode after 30s > 150% : load transfers to Bypass mode after 500ms	
Output overload (Bypass mode)	100-105% : no alarm 105-125% : continue working and alarm 125-150% : UPS shuts down after 30s	
Voltage waveform	Sinewave	
Harmonic distortion	< 1% THDV on linear load < 5% THDV on non-linear load	

Transfer time	Online mode: 0 ms (no break) High Efficiency mode: 10ms maximum (due to loss of utility)
Power factor	1
Load crest ratio	3 to 1

* for 208V output, the load level will be derating to 90%.

Table 7. Electrical output connections

Model	Output connection	Output cable
Eaton DX RT 6000VAIN	Hardwired	Not provided
Eaton DX RT 6000VAXLIN		
Eaton DX RT 10000VAIN		
Eaton DX RT 10000VAXLIN		

Table 8. Environmental and safety

Certifications	EN 62040-1 IEC/EN 62040-2: Cat. C3 IEC/EN 62040-3 EN 60950-1
EMC (Emissions)*	Conduction: C3 IEC/EN 62040-2 Radiation: C3 IEC/EN 62040-2
EMC (Immunity)	IEC 61000-4-2, Level 3 IEC 61000-4-3, Level 3 IEC 61000-4-4, Level 4 (also on signal ports) IEC 61000-4-5, Level 4, Criteria B IEC 61000-4-6, Level 3 IEC 61000-4-8, Level 4 IEC 61000-4-11

* for output cable < 10m.

Agency markings	CE
Operating temperature	0~40°C full load no derating 40~50°C output power derating to 50% load, Charger current derating 50%
Storage temperature	-15 to 40°C (32 to 104°F) with batteries -25 to 60°C (5 to 140°F) without batteries
Transit temperature	-25 to 55°C (-13 to 130°F)
Relative humidity	0 to 95% no condensing

Operating altitude	Up to 3,000 meters (9,843 ft) above sea level with 10% derating per 1000m
Transit altitude	Up to 10,000 meters (32,808 ft) above sea level
Audible noise	< 50 dBA at 1 meter typical for 6kVA models < 55 dBA at 1 meter typical for 10kVA models

Table 9. Battery

	EBMs
Rack configuration	192Vdc 16 x 12V, 7Ah 192Vdc 16 x 12V, 9Ah
Fuses	100A for 10kVA models and EBM
Type	Sealed, maintenance-free, valve-regulated, lead-acid, with minimum 3-year float service life at 25°C (77°F). Lifetime is reduced above 30 °C.
Monitoring	Advanced monitoring for earlier failure detection and warning
Battery port	External ANEN-SA30 connector on power module for connection to EBM
EBM battery cable length	100cm for tower models 50cm for RT models

Table 10. Communication options

Communication bay	available independent communication bay for connectivity cards
Compatible connectivity cards	MODBUS card NMC card AS400 card
Communication ports	RS-232 (DB9): 2400 bps USB 2.0: full speed
Dry out	2 pins jumper (normally closed)
Dry in	2 pins jumper (normally closed)
Emergency Power Off	3 pins jumper (normally closed)

10 Glossary

Bypass AC source	Source supplying the bypass line. The equipment can be transferred to the bypass line if an overload occurs on the UPS output, for maintenance or in the event of a malfunction.
Frequency converter	Operating mode used to convert the AC-power frequency between the UPS input and output (50Hz -> 60Hz or 60Hz -> 50Hz).
Low-battery warning	This is a battery-voltage level indicating that battery power is low and that the user must take action to prevent the imminent break in the supply of power to the load.
Backup time	Time during which the load can be supplied by the UPS operating on battery power.
Load	Devices or equipment connected to the UPS output.
HE mode	Operating mode by which the load is supplied directly by the AC source if it is within the tolerances defined by the user. This mode reduces the consumption of electrical power
Manual bypass	Rotary switch controlled by the user, used to connect the loads directly to the AC source. Transfer of the load to the manual bypass enables UPS maintenance without interrupting the supply of power to the connected loads.
Normal (double conversion) mode	The normal UPS operating mode in which the AC source supplies the UPS which in turn supplies the connected loads (after electronic double conversion).
Normal AC source	Normal source of power for the UPS.
Relay contacts	Contacts supplying information to the user in the form of signals.
UPS	Uninterruptible Power Supply.

614-02180XT1